



Maylandsea Bay Sailing Club

Honda Petrol Pressure Washer

Member Operating Guide

- **Only Fully Trained & Suitably Qualified Persons May Use This Machine**
- Training is required before using the Honda Pressure Washer (HPW) for the first time.
 - This is a petrol engine, therefore the operation is different from the previous plug in and use, electric ones.
- **Gary Van Blerk & Kenny Hobbs** are the custodians and **Trainers** of this equipment.
- Gary & Kenny will maintain the equipment including servicing.
 - If when using the HPW any problems or questions arise, please contact Gary or Kenny
- The HPW unit is stored in the garage behind the clubhouse
- The HPW unit is fitted onto a flat bed trolley along with the fresh water hose
 - Should the HPW be used on or at the top of the ramp, please make sure that the trolley wheels are fully chocked
- Connect the hose to the machine and the cold water tap near the west ramp
- As the HPW is driven by a petrol engine, the working distance of the machine is only governed by the length of the fresh water hose.
- The pressure hose from the HPW unit to the spray lance is 20 Metres therefore enabling a good distance of use.
- The HPW uses unleaded petrol, kept in the petrol store
- Please make sure that after using the HPW it is clean and dry before returning it to the garage storage and the petrol store is secured